

Habitat for Humanity of Monroe County
Quick Guide: Installing Pre-hung Interior Doors

Tools	Materials
Tape measure; pencil Pneumatic nail gun 6' level Utility knife Small scraps of 7/16" OSB	Pre-hung door with split jamb 18 gauge finish nails Shims Putty
Tips	
<p>Be sure the door to be installed opens in the correct direction!</p> <p>Check plumbness of hinge-side rough opening. If plumb, place door in opening and rest jamb on scraps of 7/16" OSB if carpet will be installed. Otherwise, rest on floor. Nail through hinge-side jamb above and below each hinge.</p> <p>If not plumb, use shims to plumb, placing them behind the hinges. Nail as above.</p> <p>Plumb the latch side using shims if necessary; nail through jamb above and below latch, near the top and bottom, and halfway between latch and top and bottom.</p> <p>Install the other side of the split jamb; holding jamb together, nail through the door stop. Nail through door casing on both sides about every 16". Fill holes with putty.</p>	